






UPGRADE C-MAP ESSENTIALS CARD TO A 4D WIDE COVERAGE AREA AT 40% OFF RETAIL

1. After registering the C-MAP ESSENTIALS card go to YOUR MAPS and select **UPGRADE TO A C-MAP 4D WIDE** chart.




2. Under 'Premium Upgrade Options' choose **UPGRADE** then click on **GET YOUR CHARTS NOW (A)**.

*Note: Upgrading to a C-MAP 4D WIDE coverage area will overwrite the Essentials data. Click **PROCEED (B)** to launch the cartridge preview map or **CANCEL** to choose another option.*




3. Using the **CARTRIDGE PREVIEW** map, locate the desired chart coverage area then choose **BUY (C)**. *Note: Only select **BUY (C)** once you are sure of the coverage area. The selected chart cannot be changed and all **ESSENTIALS** chart data will be overwritten. The price listed will include the premium discount as 40% off retail.*






If the following message is shown anytime during the chart selection process, then please contact an authorized [C-MAP Dealer](#) or our [Customer Support](#) team for additional upgrade options.

This map is too big to fit your SD card
Please contact dealer for more options



4. Proceed with CHECKOUT (D).



5. Enter Billing and Payment information then confirm purchase by entering your C-MAP Maps Store password. Select **PAY ONLINE (E)**. *Note: A purchase confirmation e-mail will be sent to you from the C-MAP Web Store.*

Select Payment Type.
Use existing card recorded under YOUR ACCOUNT or enter a NEW credit card.

Enter Billing INFO.
* denote mandatory fields.

Confirm purchase by entering your C-MAP Maps Store Password then click on PAY ONLINE (E).




6. After successful completion of the chart purchase, Maps Manager will launch showing the selected chart ON THE CLOUD.

For Raymarine MFDs choose from (F):




- **DOWNLOAD 4D MAX** – data contains only 2D vector maps.
- **DOWNLOAD 4D MAX+** - data contains 2D & 3D vector, Dynamic Raster & Satellite maps.

For Raymarine Dragonfly select **DOWNLOAD 4D MAX (G)**:




7. After selecting download, the chart will move to ON THE DEVICE (H) - starting the process of overwriting the ESSENTIALS data. *Note: both the Essentials chart title and the C-MAP 4D WIDE chart will appear ON THE DEVICE until the programming process is complete.*






The download can be PAUSED and RESUMED at anytime. If the programming window is closed, return to YOUR MAPS and click on **APPLY TO** to relaunch MAPS MANAGER - then select **PROGRAM SD**.




The progress bar will show download percentage completed. Click on the arrow to view additional download details including file size and remaining download time.





- Once the download is completed, the C-MAP 4D chart will show as **READY (I)** under ON THE DEVICE. The SD card can now be inserted into the Raymarine chartplotter. *Note: The C-MAP Essentials chart data will no longer be shown under ON THE DEVICE.*



Country	Phone	E-Mail
Italy, Spain, Portugal, France, Croatia, Turkey, Holland, Belgium, Greece and other European countries not listed below.	+39 0585 794 800	EU-customersupport@c-map.com
UK & Ireland		
Germany, Austria, Switzerland		
Poland		
Norway, Denmark, Iceland, Greenland	+47 51 46 47 99	
Sweden, Finland	+39 0585 794 800	
Africa & Middle East		
Russia	+7 812 327 9894	RU-lightmarine@c-map.com
Asia and Australia	+61 2 98 08 6200	apac-customersupport@c-map.com
The Americas and Caribbean	Toll free: +1 800 424 2627	US-customersupport@c-map.com