



12V Power

ST to STNG Converter

yellow cable

~ 15 ft
Seataalk Cable to
flybridge

Seataalk Hub

Rudder Angle Indicator

Seataalk

4006 Compute

12V Power

ST6001 Control Unit

ST60 Depth

Autopilot Wireless Transmitt

Seataalk Plus for Charging

Autopilot Wireless Remote